

Webcam Cover 3.0

Instructions:

- 1) Remove double-sided tape tabs.
- Position base cover over the camera lens, then press firmly.
- Once installed, simple slide right to open and left to close.

WARNING units placed directly on the screen could provide a pressure point if the device is dropped or slammed closed that could damage the screen

BLUE LINE IS THE SAFETY LINE 3.25X2.25

RED LINE ISTHE CUT LINE 3.5X2.5

BI FFD